

Dimenzije	SCH 40	SCH 80
1" x 1/2"		•
1 1/2" x 1 1/4"	•	
1 1/4" x 1"	•	
1 1/2" x 1"	•	
2" x 1"	•	
2" x 1"		•
2 1/2" x 1 1/4"	•	
1" x 1/2"	•	
2" x 1 1/2"	•	
6" x 4"	•	
10" x 8"	•	
1" x 3/4"	•	
3" x 2 1/2"	•	
4" x 2 1/2"	•	
4" x 3"	•	
6" x 4"	•	
8" x 6"	•	
8" x 6"		•
10" x 8"	•	
2 1/2" x 1 1/2"	•	
2 1/2" x 2"	•	
3" x 1 1/2"	•	
3" x 2"	•	
3" x 2"		•
4" x 2"	•	
4" x 2"		•
3" x 2 1/2"	•	
4" x 2 1/2"	•	
4" x 3"	•	
4" x 3"		•
5" x 4"	•	
6" x 3"	•	
8" x 4"	•	
8" x 6"	•	
10" x 6"	•	
12" x 6"	•	
12" x 8"	•	
12" x 10"	•	
14" x 10"	•	
14" x 12"	•	
1 1/2" x 1"		•
2" x 1"	•	
2" x 1 1/2"	•	
3" x 2"	•	
1 1/4" x 3/4"	•	